



# MEC-POL FO500S

## Cerium Oxide

### FIELDS OF APPLICATION

- Pre-silver cleaning of mirrors
- Glass and mirror bevelling

### PHYSICAL AND CHEMICAL DATA

Average Particle size (Coulter Counter) d50:  
pH-value of slurry:  
Loss on ignition:

### TYPICAL

1,7 – 2,3  $\mu\text{m}$   
6,0 – 7,0  
2,4 %

### INSTRUCTIONS FOR USE:

Concentration of slurry:	Pre-silver cleaning:	20 – 30 g/l
	Bevelling:	50 – 60 g/l
Suggested slurry temperature:	35 – 40 °C	
Polishing pads:	Whatever is suitable and brushes	

### PACKING:

PE-containers with 25 kgs net each

### CAUTIONS:

Use normal Industrial precautions

07/97/1